



ASSEMBLY INSTRUCTIONS
Do not fully tighten bolts until assembly is complete.

4



Fully tighten all bolts

5



Cover the fabric


dh

Model: _____

Lot No: _____

Date of Purchase: _____

**EMMA
DINING CHAIR**



ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll- free customer service number and have this assembly manual open to the parts list ready to provide the model name, and part name or number.



Customer Service

1-877-864-5752

8:30 AM PST - 4:30 PM PST (Monday - Friday)

Website: www.dwellhom.com


Missing Parts: parts@dwellhom.com

Warranty Information: www.dwellhom.com/warranty


WARNING: This product may contain small components, please ensure they are kept away from small children.

PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.



1




Partly screw in bolts, but do not fully tighten

ASSEMBLY INSTRUCTIONS


Do not fully tighten bolts until assembly is complete.

2



Partly screw in bolts, but do not fully tighten

3



Stand the chair upright & ensure it is level before tightening all bolts