



SAVE THESE INSTRUCTIONS

SONOMA HEADBOARD ASSEMBLY INSTRUCTIONS

STYLE #: 62SNRHB01EX, 62SNRHB01BN, 62SNRHB01DR, 62SNRHB03TY,
62SNRHB03DV, 62SNRHB02AP, 62SNRHB02AG, 62SNRHB02CT

ASSEMBLE ON A FLAT, PROTECTED SURFACE.

PART LIST	FIGURE	QUANTITY	DESCRIPTION
A		1	HEADBOARD
B		1	LEFT LEG
C		1	RIGHT LEG
D		8 PCS + 1 PC	BOLT (M6 x 2")
E		8 PCS + 1 PC	FLAT WASHERS
F		1	ALLEN WRENCH

* PLEASE NOTE THAT WHILE THE HEADBOARD YOU HAVE PURCHASED MAY NOT MATCH THE SILHOUETTE SHOWN IN PARTS LIST A, THE ASSEMBLY INSTRUCTIONS ARE THE SAME.


ASSEMBLY INSTRUCTIONS (CONTINUED)

STYLE #: 62SNRHB01EX, 62SNRHB01BN, 62SNRHB01DR, 62SNRHB03TY,
62SNRHB03DV, 62SNRHB02AP, 62SNRHB02AG, 62SNRHB02CT

STEP # 1

A. REMOVE THE FABRIC COVERS FROM THE BACK OF THE HEADBOARD (A).


B. TAKE OUT THE LEGS (B & C) AND HARDWARE.



STEP # 2


THE HEADBOARD CAN BE ADJUSTED TO DIFFERENT HEIGHTS. SELECT THE DESIRED HEIGHT.

A. ATTACH LEGS (B+C) TO HEADBOARD (A) USING BOLTS (D) AND FLAT WASHERS (E). SECURELY TIGHTEN WITH ALLEN WRENCH (F).




STEP # 3

A. REPLACE THE FABRIC COVERS FROM STEP 1 TO THE BACK OF THE HEADBOARD (A).




STEP # 4

HEADBOARD ASSEMBLY IS COMPLETE.



HEADBOARD MOUNTING INSTRUCTIONS

**STYLE #: 62SNRHB01EX, 62SNRHB01BN, 62SNRHB01DR, 62SNRHB03TY,
62SNRHB03DV, 62SNRHB02AP, 62SNRHB02AG, 62SNRHB02CT**


PART LIST	FIGURE	QUANTITY	DESCRIPTION
1		4 PCS + 1 PC	BOLT (M6 X 2")
2		8 PCS + 1 PC	FLAT WASHERS
3		4 PCS + 1 PC	NUT
4		1	WRENCH

STEP # 5

A. HEADBOARD MOUNTING TO YOUR BED FRAME (BED FRAME NOT INCLUDED). USE BOLTS (1), FLAT WASHERS (2), AND NUTS (3) TO MOUNT HEADBOARD (A) TO THE BED FRAME. CHOOSE THE APPROPRIATE SLOTS ON THE LEGS TO FIT TO YOUR BED FRAME.

NOTE: TWIN SIZE ONLY HAS ONE SLOT PER LEG.

B. TIGHTEN SECURELY WITH WRENCH (4) AND ALLEN WRENCH (F).



** WE RECOMMEND THAT YOU SAVE THE ALLEN WRENCH (F) AND WRENCH (4) AND PERIODICALLY TIGHTEN ALL BOLTS AND NUTS.

CARE AND CLEANING:

SPOT CLEAN USING & DAMP CLEAN CLOTH. DO NOT RUB.

INTENDED FOR INDOOR USE ONLY.