








SAVE THESE INSTRUCTIONS
SONOMA WICKER CHAIR SET ASSEMBLY INSTRUCTIONS
STYLE #: 71SRRWK38
ASSEMBLE ON A FLAT, PROTECTED SURFACE.

PART LIST	FIGURE	QUANTITY	DESCRIPTION
A		1 PC	CHAIR
B		1 PC	BACK SKIRT
C		5 PCS + 1 PC	BOLT (Φ8X16MM)
D		5 PCS + 1 PC	FLAT WASHER
E		5 PCS + 1 PC	BOLT CAP
F		1 PC	ALLEN WRENCH
G		1 PC	CUSHION


ASSEMBLY INSTRUCTIONS (CONTINUED)

STYLE #: 71SRRWK38

STEP 1

A. PLACE CHAIR (A) UPSIDE DOWN AS SHOWN ON A FLAT, PROTECTED SURFACE.

B. CONNECT BACK SKIRT (B) TO CHAIR (A) AT BACK CONNECTION FIRST WITH BOLT (C) AND FLAT WASHER (D) USING ALLEN WRENCH (F). DO NOT TIGHTEN COMPLETELY.




STEP 2

A. CONNECT BACK SKIRT (B) TO CHAIR (A) AT FRONT CONNECTIONS WITH BOLTS (C) AND FLAT WASHERS (D) USING ALLEN WRENCH (F). DO NOT TIGHTEN COMPLETELY.

B. TIGHTEN COMPLETELY ALL BOLTS (C) FROM STEPS 1 & 2.

C. COVER BOLTS (C) WITH BOLT CAPS (E).



ASSEMBLY INSTRUCTIONS (CONTINUED)


STYLE #: 71SRRWK38

STEP 3

A. ROTATE ASSEMBLED CHAIR TO UPRIGHT POSITION.

B. PLACE CUSHION (G) ON CHAIR SEAT.

C. ASSEMBLY IS COMPLETE.



**** WE RECOMMEND THAT YOU SAVE THE ALLEN WRENCH (F) AND PERIODICALLY TIGHTEN ALL BOLTS**

WEIGHT LIMIT

CHAIR: 300 LBS

CARE AND CLEANING

WASH FRAME WITH MILD SOLUTION OF SOAP AND WATER, RINSE WITH CLEAN WATER AND DRY THOROUGHLY.

CUSHIONS SHOULD BE SPOT CLEANED WITH A SOFT CLOTH.

DO NOT STAND OR CLIMB ON THE CHAIR.

WARRANTY

1 YEAR LIMITED WARRANTY FOR FRAME, WEAVE AND CUSHIONS.

WHAT IS COVERED:

WE WARRANT TO THE ORIGINAL PURCHASER FOR ONE YEAR, FROM THE DATE OF PURCHASE, THAT THE FRAME, RESIN WEAVE AND CUSHIONS WILL BE FREE FROM MANUFACTURING DEFECTS. THIS WARRANTY ALSO COVERS PEELING, CRACKING, BLISTERING, DISCOLORATION, OR FADING FOR THIS ONE YEAR PERIOD.

WHAT IS NOT COVERED:

IT REMAINS THE CUSTOMER'S RESPONSIBILITY FOR FREIGHT AND PACKAGING CHARGES TO AND FROM OUR SERVICE CENTER. THIS WARRANTY DOES NOT COVER COMMERCIAL USE, ACTS OF NATURE, FIRE, FREEZING, AND ABUSIVE USE. DISCOLORATION OR FADING OF THE FINISH OR FABRICS AS A RESULT OF CHEMICALS OR SPILLS IS NOT COVERED. GLASS TABLETOP BREAKAGE AND CORROSION OR RUSTING OF HARDWARE ARE NOT COVERED. IN ADDITION, PURCHASED PARTS ARE NOT COVERED UNDER THIS WARRANTY. PROOF OF PURCHASE (DATED REGISTER RECEIPT) IS REQUIRED FOR WARRANTY CLAIMS. WE RESERVE THE RIGHT TO MAKE SUBSTITUTIONS WITH SIMILAR MERCHANDISE, IF THE MODEL IS NO LONGER IN PRODUCTION. WARRANTY IS TO THE ORIGINAL PURCHASER AND IS NOT TRANSFERABLE. AS SOME STATES DO NOT ALLOW EXCLUSIONS OR LIMITATIONS ON AN IMPLIED WARRANTY, THE ABOVE EXCLUSIONS AND LIMITATIONS MAY NOT APPLY. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

CUSTOMER SERVICE

FOR REPLACEMENT PARTS OR FOR ADDITIONAL INFORMATION

CALL: 1-800-327-2978 9AM TO 5PM EST, Monday-Friday

EMAIL: info@grandbasketco.com