









SAVE THESE INSTRUCTIONS
CLAREMONT HIGH DINING TABLE
STYLE #: 61SRR2701CLR
ASSEMBLE ON A FLAT, PROTECTED SURFACE.

PART LIST	FIGURE	QUANTITY	DESCRIPTION
A		1 PC	TABLE TOP
B		4 PCS	LEG
C		1 PC	LEG CONNECTOR
D		1 PC	LEG CONNECTOR
E		8 + 1 PCS	SHORT BOLT (M6*15)
F		8 + 1 PCS	LONG BOLT (M6*28)
G		16 + 1 PCS	FLAT WASHER
H		1 PC	ALLEN WRENCH

CLAREMONT HIGH DINING TABLE


STYLE #: 61SRR2701CLR

ASSEMBLY INSTRUCTIONS (CONTINUED)

STEP 1

A. PLACE TABLE TOP (A) UPSIDE DOWN ON A FLAT, PROTECTED SURFACE.


B. ATTACH LEGS (B) TO TABLE TOP (A) WITH FLAT WASHER (G) AND BOLT (E) USING ALLEN WRENCH (H). DO NOT TIGHTEN COMPLETELY.



STEP 2

A. ATTACH LEG CONNECTOR (C) TO LEGS (B) WITH FLAT WASHER (G) AND BOLT (F) USING ALLEN WRENCH (H). DO NOT TIGHTEN COMPLETELY.

B. ATTACH LEG CONNECTOR (D) TO LEGS (B) WITH FLAT WASHER (G) AND BOLT (E) USING ALLEN WRENCH (H). DO NOT TIGHTEN COMPLETELY.



STEP 3

A. TURN TABLE TO UPRIGHT POSITION SO THAT IT STANDS STABLE ON THE FLOOR.

B. TIGHTEN ALL BOLTS SECURELY USING ALLEN WRENCH (H). TIGHTEN THE LEG CONNECTOR (C, D) FIRST, THEN TIGHTEN THE LEG (B) TO TABLE TOP (A).

C. KEEP ALLEN WRENCH (H) TO TIGHTEN ALL BOLTS (E) AND (F) PERIODICALLY AS NEEDED.



WEIGHT LIMIT

200 LBS

CARE AND CLEANING

IN ORDER TO PROLONG THE LIFE OF YOUR TABLE, PLEASE STORE IN DRY SHELTERED PLACE WHEN NOT IN USE OR DURING INCLEMENT WEATHER.

WARRANTY

1 YEAR LIMITED WARRANTY FOR FRAME.

CUSTOMER SERVICE: PLEASE NOTE - DO NOT RETURN THIS ITEM TO THE RETAILER.

CUSTOMER SERVICE HOT LINE: 1-866-905-4107

SERVICE HOURS: 11:30 A. M. to 8:00 P. M. EASTERN STANDARD TIME /8:30 A. M. to 5:00 P. M. PACIFIC STANDARD TIME

WEBSITE: WWW.YOTRIJOINT.COM

TO ASSIST YOU BETTER, PLEASE GATHER THE FOLLOWING INFORMATION BEFORE CALLING CUSTOMER SERVICE: PRODUCT NAME AND STYLE NUMBER, DESCRIPTION AND OR IMAGES OF THE ISSUE, ORIGINAL STORE PURCHASE RECEIPT.