## **SAVE THESE INSTRUCTIONS**

### 9' CRANK & TILT UMBRELLA

# STYLE #: 61SRR31CNT ASSEMBLE ON A FLAT, PROTECTED SURFACE.

PART LIST	FIGURE	QUANTITY	DESCRIPTION
А		1 PC	UMBRELLA
В		1 PC	BASE POLE
С		1 PC	FINIAL


## 9' CRANK & TILT UMBRELLA STYLE #: 61SRR31CNT

## ASSEMBLY INSTRUCTIONS (CONTINUED)

#### STEP 1


A. Attach finial (C) to top of umbrella (A) by turning clockwise until secure. Do not over tighten.

B. Insert base pole (B) into umbrella (A). Turn counter clockwise to tighten securely.



#### STEP 2


A. Once the assembled umbrella is secured in its desired location, to open turn the crank handle clockwise to gradually unfold the canopy. Do not over extend.



#### STEP 3

A. To tilt the umbrella, depress the button at the top of the umbrella pole and guide the canopy to the left or right position.


B. To further adjust the sunshade rotate the entire umbrella base to desired position.



#### STEP 4

A. To close the umbrella, return canopy to upright centered position by depressing the button and guiding the canopy to centered position.

B. Turn the crank handle counter clockwise to gradually fold the canopy into closed position.



#### 9' CRANK & TILT UMBRELLA

#### STYLE #: 61SRR31CNT

#### **ASSEMBLY INSTRUCTIONS (CONTINUED)**

#### **USE AND CARE**

- 1. For outdoor use only.
- 2. Use with weighted umbrella stand/base (not included).
- 3. Close umbrella when not in use and during high winds.
- 4. In order to prolong the life of your umbrella, when not in use or during inclement weather, store in dry sheltered location.
- 5. Keep away from fire or flame.
- 6. To clean, hand wash with mild soap and cool water. Do not use abrasive material, cleansers or bleach products.
- 7. Do not use sharp tools with this product, as it may scratch the metal finish.
- 8. The metal surface has a special rust protection coating. Please take special care to prevent scratches to the finish. If scratched or surface peels, please purchase touch up paint to coat and to protect those exposed areas.

#### WARRANTY

1 YEAR LIMITED WARRANTY. Scratches and damage due to normal wear and tear not covered. We are not responsible for normal wear and tear, corrosion and rusting, wind damage, acts of nature, or lack of proper care.