










## SAVE THESE INSTRUCTIONS

### SONOMA CORONADO DECO BACK STATIONARY CHAIR ASSEMBLY INSTRUCTIONS

STYLE #: 71SRRSL03

ASSEMBLE ON A FLAT, PROTECTED SURFACE.

| PART LIST | FIGURE  | QUANTITY     | DESCRIPTION              |
|-----------|---|--------------|--------------------------|
| A         |    | 1 PC         | BACK                     |
| B         |    | 1 PC         | RIGHT ARM                |
| C         |    | 1 PC         | SEAT                     |
| D         |    | 1 PC         | LEFT ARM                 |
| E         |    | 2 PCS + 1 PC | SHORT BOLT<br>(M6*15MM)  |
| F         |    | 4 PCS + 1 PC | MEDIUM BOLT<br>(M6*30MM) |
| G         |    | 2 PCS + 1 PC | LONG BOLT<br>(M6*40MM)   |
| H         |  | 8 PCS + 1 PC | FLAT WASHER              |
| I         |  | 1 PC         | ALLEN WRENCH             |

## ASSEMBLY INSTRUCTIONS (CONTINUED)


STYLE #: 71SRRSL03

### STEP 1

A. PLACE RIGHT ARM (B) ON A FLAT, PROTECTED SURFACE.

B. CONNECT SEAT (C) TO RIGHT ARM (B) WITH MEDIUM BOLTS (F) AND FLAT WASHERS (H) USING ALLEN WRENCH (I). DO NOT TIGHTEN COMPLETELY.

C. CONNECT BACK (A) TO RIGHT ARM (B) WITH SHORT & LONG BOLTS (E & G) AND FLAT WASHERS (H) USING ALLEN WRENCH (I). DO NOT TIGHTEN COMPLETELY.




### STEP 2

A. PLACE LEFT ARM (D) ON A FLAT, PROTECTED SURFACE.

B. CONNECT SEAT (C) TO LEFT ARM (D) WITH MEDIUM BOLTS (F) AND FLAT WASHERS (H) USING ALLEN WRENCH (I). DO NOT TIGHTEN COMPLETELY.

C. CONNECT BACK (A) TO LEFT ARM (D) WITH SHORT & LONG BOLTS (E & G) AND FLAT WASHERS (H) USING ALLEN WRENCH (I). DO NOT TIGHTEN COMPLETELY.




### STEP 3

A. TIGHTEN ALL BOLTS SECURELY USING ALLEN WRENCH (I).

B. ROTATE CHAIR TO THE UPRIGHT POSITION.

C. ASSEMBLY IS COMPLETE.



## **ASSEMBLY INSTRUCTIONS (CONTINUED)**

**STYLE #: 71SRRSL03**

**\*\* WE RECOMMEND THAT YOU SAVE THE ALLEN WRENCH AND PERIODICALLY TIGHTEN ALL BOLTS.**

### **WEIGHT LIMIT**

300 LBS

### **CARE AND CLEANING**

WIPE CLEAN WITH A MILD SOAP AND WATER SOLUTION, RINSE WITH CLEAN WATER, AND DRY THOROUGHLY.

DO NOT STAND OR CLIMB ON CHAIR.

IN ORDER TO PROLONG THE LIFE OF YOUR CHAIR, PLEASE STORE IN DRY SHELTERED PLACE WHEN NOT IN USE OR DURING INCLEMENT WEATHER.

### **WARRANTY**

1 YEAR LIMITED WARRANTY FOR FRAME.

CUSTOMER SERVICE: PLEASE NOTE - DO NOT RETURN THIS ITEM TO THE RETAILER.

CUSTOMER SERVICE HOT LINE: 1-866-905-4107

WEBSITE: [WWW.YOTRIOINT.COM](http://WWW.YOTRIOINT.COM)

TO ASSIST YOU BETTER, PLEASE GATHER THE FOLLOWING INFORMATION BEFORE CALLING CUSTOMER SERVICE:  
PRODUCT NAME AND STYLE NUMBER, DESCRIPTION AND OR IMAGES OF THE ISSUE, ORIGINAL STORE PURCHASE RECEIPT.