### **SAVE THESE INSTRUCTIONS**

# SONOMA BRAMPTON ARM DINING CHAIR ASSEMBLY INSTRUCTIONS STYLE #: 71SRRWK35

#### ASSEMBLE ON A FLAT, PROTECTED SURFACE.


PART LIST	FIGURE	QUANTITY	DESCRIPTION
А		1 PC	CHAIR SEAT
В		2 PCS	FRONT LEG
С		1 PC	RIGHT BACK LEG
D		1 PC	LEFT BACK LEG
E	Jumum	12 PCS + 1 PCS	BOLT (M6*15MM)
F		12 PCS + 1 PCS	FLAT WASHER
G		1 PC	ALLEN WRENCH
Н		1 PC	CUSHION

## ASSEMBLY INSTRUCTIONS (CONTINUED) STYLE #: 71SRRWK35

#### STEP 1

A. PLACE CHAIR SEAT (A) UPSIDE DOWN ON A FLAT, PROTECTED SURFACE.


B. CONNECT TWO FRONT LEGS (B) TO CHAIR SEAT (A) WITH FLAT WASHERS (F) AND BOLTS (E) USING ALLEN WRENCH (G). TIGHTEN COMPLETELY.



#### STEP 2

A. CONNECT RIGHT BACK LEG (C) TO CHAIR SEAT (A) WITH FLAT WASHERS (F) AND BOLTS (E) USING ALLEN WRENCH (G). TIGHTEN COMPLETELY.

B. CONNECT LEFT BACK LEG (D) TO CHAIR SEAT (A) WITH FLAT WASHERS (F) AND BOLTS (E) USING ALLEN WRENCH (G). TIGHTEN COMPLETELY.




#### STEP 3

A. ROTATE CHAIR TO UPRIGHT POSITION SO THAT IT STANDS STABLE ON THE FLOOR.

B. PLACE CUSHION (H) ON SEAT.

C. ASSEMBLY IS COMPLETE.



### ASSEMBLY INSTRUCTIONS (CONTINUED)

**STYLE #: 71SRRWK35** 

\*\* WE RECOMMEND THAT YOU SAVE THE ALLEN WRENCH AND PERIODICALLY TIGHTEN ALL BOLTS.

#### **WEIGHT LIMIT**

250 LBS

#### **CARE AND CLEANING**

FRAME: WIPE CLEAN WITH A MILD SOAP AND WATER SOLUTION, RINSE WITH CLEAN WATER, AND DRY THROUGHLY.

CUSHION: SPOT CLEAN WITH A SOFT CLOTH.

DO NOT STAND OR CLIMB ON CHAIR.

IN ORDER TO PROLONG THE LIFE OF YOUR CHAIR, PLEASE STORE IN DRY SHELTERED PLACE WHEN NOT IN USE OR

DURING INCLEMENT WEATHER.

#### WARRANTY

1 YEAR LIMITED WARRANTY FOR FRAME.

CUSTOMER SERVICE: PLEASE NOTE - DO NOT RETURN THIS ITEM TO THE RETAILER.

CUSTOMER SERVICE HOT LINE: 1-866-905-4107

WEBSITE: WWW.YOTRIOINT.COM

TO ASSIST YOU BETTER, PLEASE GATHER THE FOLLOWING INFORMATION BEFORE CALLING CUSTOMER SERVICE: PRODUCT NAME AND STYLE NUMBER, DESCRIPTION AND OR IMAGES OF THE ISSUE, ORIGINAL STORE PURCHASE