SAVE THESE INSTRUCTIONS

SONOMA CLAREMONT UMBRELLA TABLE ASSEMBLY INSTRUCTIONS

STYLE #: 71SRRUM04

ASSEMBLE ON A FLAT, PROTECTED SURFACE.


PART LIST	FIGURE	QUANTITY	DESCRIPTION
А		1 PC	ТОР
В		4 PCS	LEG
С		4 PCS	SIDE
D		1 PC	UMBRELLA HOLE CAP
E		20 PCS + 1 PC	BOLT (M6*15MM)
F	0	20 PCS + 1 PC	FLAT WASHER
G		1 PC	ALLEN WRENCH

ASSEMBLY INSTRUCTIONS (CONTINUED) STYLE #: 71SRRUM04

STEP 1


A. PLACE SIDE (C) ON A FLAT, PROTECTED SURFACE.

B. ATTACH LEGS (B) TO SIDE (C) USING BOLTS (E) AND FLAT WASHERS (F). LOOSELY TIGHTEN WITH ALLEN WRENCH (G).




STEP 2

A. CONNECT ADDITIONAL SIDES (C) TO LEGS (B)
OF THE ASSEMBLED UNIT USING BOLTS (E) AND
FLAT WASHERS (F). LOOSELY TIGHTEN WITH
ALLEN WRENCH (G).



STEP 3

A. CONNECT REMAINING TWO LEGS (B) TO SIDES (C) OF THE ASSEMBLED UNIT USING BOLTS (E) AND FLAT WASHERS (F). LOOSELY TIGHTEN WITH ALLEN WRENCH (G).




ASSEMBLY INSTRUCTIONS (CONTINUED) STYLE #: 71SRRUM04

STEP 4

A. ROTATE THE ASSEMBLED UNIT TO THE STANDING POSITION.

B. CONNECT THE LAST SIDE (C) TO LEGS (B) OF THE ASSEMBLED UNIT USING BOLTS (E) AND FLAT WASHERS (F). LOOSELY TIGHTEN WITH ALLEN WRENCH (G).




STEP 5

A. PLACE TOP (A) UPSIDE DOWN ON A FLAT, PROTECTED SURFACE.

B. CONNECT THE FOUR LEGS (B) TO TOP (A) USING BOLTS (E) AND FLAT WASHERS (F).

C. TIGHTEN ALL BOLTS (E) WITH ALLEN WRENCH (G).




STEP 6

A. ROTATE ASSEMBLED UNIT TO THE UPRIGHT POSITION.

B. PUT UMBRELLA HOLE CAP (D) INTO THE UMBRELLA HOLE ON TOP (A).

B. ASSEMBLY IS COMPLETE.



ASSEMBLY INSTRUCTIONS (CONTINUED)

STYLE #: 71SRRUM04

** WE RECOMMEND THAT YOU SAVE THE ALLEN WRENCH AND PERIODICALLY TIGHTEN ALL BOLTS.

WEIGHT LIMIT

165 LBS

CARE AND CLEANING

- 1. DO NOT SIT, STAND, OR CLIMB ON TABLE.
- 2. WIPE CLEAN WITH A SOFT, DAMP CLOTH AS NEEDED.
- 3. MUST BE USED WITH AN UMBRELLA BASE.
- 4. IN ORDER TO PROLONG THE LIFE OF YOUR TABLE, PLEASE STORE IN DRY SHELTERED PLACE WHEN NOT IN USE OR DURING INCLEMENT WEATHER.

WARRANTY

1 YEAR LIMITED WARRANTY FOR FRAME.

CUSTOMER SERVICE: PLEASE NOTE - DO NOT RETURN THIS ITEM TO THE RETAILER.

CUSTOMER SERVICE HOT LINE: 1-866-905-4107

WEBSITE: WWW.YOTRIOINT.COM

TO ASSIST YOU BETTER, PLEASE GATHER THE FOLLOWING INFORMATION BEFORE CALLING CUSTOMER SERVICE: PRODUCT NAME AND STYLE NUMBER, DESCRIPTION AND OR IMAGES OF THE ISSUE, ORIGINAL STORE PURCHASE