












SAVE THESE INSTRUCTIONS
RAVINE LOVESEAT WITH CUSHION
STYLE #: 61SRR4525RAV

ASSEMBLE ON A FLAT, PROTECTED SURFACE.

PART LIST	FIGURE	QUANTITY	DESCRIPTION
A		1 PC	SEAT
B		1 PC	BACK
C		1 PC	LEFT SIDE
D		1 PC	RIGHT SIDE
E		2 PCS	SEAT CUSHION
F		2 PCS	BACK CUSHION
G		4 PCS	SHORT BOLT (M6*18mm)
H		9 PCS	LONG BOLT (M6*50mm)
I		13 PCS	FLAT WASHER
J		4 PCS	BOLT CAP
K		1 PC	ALLEN WRENCH

RAVINE LOVESEAT WITH CUSHION


STYLE #: 61SRR4525RAV

ASSEMBLY INSTRUCTIONS (CONT.)

STEP 1


A. PLACE BACK (B) ON A FLAT, PROTECTED SURFACE.

B. CONNECT SEAT (A) TO BACK (B) WITH FLAT WASHER (I) AND LONG BOLT (H) USING ALLEN WRENCH (K). DO NOT TIGHTEN COMPLETELY.




STEP 2

A. CONNECT FRONT LEG OF LEFT SIDE (C) TO SEAT (A) WITH FLAT WASHER (I) AND SHORT BOLT (G) USING ALLEN WRENCH (K). DO NOT TIGHTEN COMPLETELY.




STEP 3

A. CONNECT FRONT LEG OF RIGHT SIDE (D) TO SEAT (A) WITH FLAT WASHER (I) AND SHORT BOLT (G) USING ALLEN WRENCH (K). DO NOT TIGHTEN COMPLETELY.



STEP 4

A. CONNECT BOTH REAR LEGS FROM SIDES (C&D) TO BACK (B) WITH FLAT WASHER (I) AND LONG BOLT (H) USING ALLEN WRENCH (K). DO NOT TIGHTEN COMPLETELY.



RAVINE LOVESEAT WITH CUSHION

STYLE #: 61SRR4525RAV


ASSEMBLY INSTRUCTIONS (CONT.)

STEP 5

A. CONNECT BOTH TOP PARTS OF ARMS FROM SIDES (C&D) TO BACK (B) WITH FLAT WASHER (I) AND LONG BOLT (H) USING ALLEN WRENCH (K).

B. TIGHTEN ALL BOLTS FROM ALL STEPS SECURELY USING ALLEN WRENCH (K).


C. PUT THE BOLT CAP (J) ON THE LONG BOLT (H).



STEP 6

A. PUT THE CUSHIONS (E&F) ON THE CHAIR.

B. RETAIN ALLEN WRENCH (K) FOR USE TO TIGHTEN BOLTS PERIODICALLY OR AS NEEDED.



WEIGHT LIMIT

500 LBS

CARE AND CLEANING

IN ORDER TO PROLONG THE LIFE OF YOUR LOVESEAT, PLEASE STORE IN DRY SHELTERED PLACE WHEN NOT IN USE OR DURING INCLEMENT WEATHER.

CLEAN WITH A DAMP CLOTH OR SPONGE USING WARM WATER AND MILD SOAP, WIPE DRY. DO NOT USE BLEACH, ACID SOLVENTS OR ABRASIVE CLEANERS ON WICKER OR FRAME PARTS.

WARRANTY

1 YEAR LIMITED WARRANTY FOR FRAME AND CUSHIONS.

CUSTOMER SERVICE: PLEASE NOTE - DO NOT RETURN THIS ITEM TO THE RETAILER.

CUSTOMER SERVICE HOT LINE: 855-259-5097

SERVICE HOURS: 9:00 A.M to 5:00 P.M EASTERN STANDARD TIME MONDAY THROUGH FRIDAY

E-MAIL: ACS@AMERICANCUSTOMERSERVICE.COM

TO ASSIST YOU BETTER, PLEASE GATHER THE FOLLOWING INFORMATION BEFORE CALLING CUSTOMER SERVICE: PRODUCT NAME AND STYLE NUMBER, DESCRIPTION AND OR IMAGES OF THE ISSUE, ORIGINAL STORE PURCHASE RECEIPT.