








SAVE THESE INSTRUCTIONS

SONOMA CORONADO DECO BACK TABLE ASSEMBLY INSTRUCTIONS

STYLE #: 71SRRSL09

ASSEMBLE ON A FLAT, PROTECTED SURFACE.

PART LIST	FIGURE	QUANTITY	DESCRIPTION
A		1 PC	TOP
B		4 PCS	LEG
C		1 PC	LEG CONNECTOR
D		8 PCS + 1 PC	SHORT BOLT (M6*15MM)
E		8 PCS + 1 PC	LONG BOLT (M6*25MM)
F		16 PCS + 1 PC	FLAT WASHER
G		1 PC	ALLEN WRENCH


ASSEMBLY INSTRUCTIONS (CONTINUED)

STYLE #: 71SRRSL09

STEP 1

A. PLACE TOP (A) UPSIDE DOWN ON A FLAT, PROTECTED SURFACE.


B. CONNECT LEGS (B) TO TOP (A) WITH SHORT BOLTS (D) AND FLAT WASHERS (F) USING ALLEN WRENCH (G). DO NOT TIGHTEN COMPLETELY.



STEP 2

A. ATTACH LEG CONNECTOR (C) TO LEGS (B) WITH LONG BOLTS (E) AND FLAT WASHERS (F) USING ALLEN WRENCH (G). DO NOT TIGHTEN COMPLETELY.

B. TIGHTEN COMPLETELY ALL BOLTS (D & F) USING ALLEN WRENCH (G).



STEP 3

A. ROTATE TABLE TO UPRIGHT POSITION.

B. ASSEMBLY IS COMPLETE.



ASSEMBLY INSTRUCTIONS (CONTINUED)

STYLE #: 71SRRSL09

**** WE RECOMMEND THAT YOU SAVE THE ALLEN WRENCH (G) AND PERIODICALLY TIGHTEN ALL BOLTS.**

WEIGHT LIMIT

110 LBS

CARE AND CLEANING

WIPE CLEAN WITH A MILD SOAP AND WATER SOLUTION, RINSE WITH CLEAN WATER, AND DRY THOROUGHLY.

DO NOT SIT, STAND, OR CLIMB ON THE TABLE.

IN ORDER TO PROLONG THE LIFE OF YOUR TABLE, PLEASE STORE IN DRY SHELTERED PLACE WHEN NOT IN USE OR DURING INCLEMENT WEATHER.

WARRANTY

1 YEAR LIMITED WARRANTY FOR FRAME.

CUSTOMER SERVICE: PLEASE NOTE - DO NOT RETURN THIS ITEM TO THE RETAILER.

CUSTOMER SERVICE HOT LINE: 1-866-905-4107

WEBSITE: WWW.YOTRIOINT.COM

TO ASSIST YOU BETTER, PLEASE GATHER THE FOLLOWING INFORMATION BEFORE CALLING CUSTOMER SERVICE: PRODUCT NAME AND STYLE NUMBER, DESCRIPTION AND OR IMAGES OF THE ISSUE, ORIGINAL STORE PURCHASE RECEIPT.