

SAVE THESE INSTRUCTIONS


SIMPLE BY DESIGN BUTTERFLY CHAIR ASSEMBLY INSTRUCTIONS

STYLE#: 73SDRSE01SH,73SDRSE01SHW,73SDRSE01JS,73SDRSE01DN,
73SDRSE01F,73SDRSE01CP,73SDRSE01PR,73SDRSE01VN

ASSEMBLE ON A FLAT,PROTECTED SURFACE.


STEP 1 TO OPEN

A. PLACE THE BOTTOM OF THE FOLDED CHAIR FRAME ON A FLAT, PROTECTED SURFACE.



STEP 2

A. OPEN THE FRAME BY EXTENDING OUTWARDS AS SHOWN.



STEP 3

A. PLACE THE CUSHION ON TOP OF CHAIR FRAME AS SHOWN.
NOTE: THE TOP IS WIDER THAN THE SEAT.


B. INSERT CHAIR FRAME INTO EACH CORNER POCKET ON THE BACK OF THE CUSHION. MAKE SURE THE CUSHION IS SECURE ON THE CHAIR FRAME.



STEP 4 TO CLOSE

A. REMOVE THE CUSHION FROM THE CHAIR FRAME. FOLD THE FRAME INWARDS.

B. CHAIR IS READY TO TRANSPORT OR STORE.



WEIGHT LIMIT

250 LBS

CARE AND CLEANING

FRAME: WIPE CLEAN WITH A SOFT, DAMP CLOTH AS NEEDED.
CUSHION: SPOT CLEAN WITH A SOFT, DAMP CLOTH AS NEEDED.
DO NOT STAND OR CLIMB ON THE CHAIR
INTENDED FOR INDOOR USE ONLY

WARRANTY

Contact our Customer Service Center at: 1-877-726-3888 or at customerservice@sinomax-usa.com