

Check out all of our products at www.BloChair.com

Care, Maintenance & Storage

- 1. Inspect your chair prior to each use.
- Keep your chair away from sharp objects. Large cuts or snags may not be repairable and will not be covered by your warranty.
- 3. Store your chair in a clean, dry place when not in use.
- 4. In case of incidental damage to your chair, a repair kit has been included. Please follow repair instructions carefully as shown on the patch.
- 5. To clean your chair, use soap and water with a wash cloth. For covered chairs, please follow care instructions on the sewn-in label.
- To store your chair, make sure it is deflated and completely dry. Store your chair in a clean, dry place at room temperature.

Service

Questions? For assembly assistance or any other questions, contact Service@BandDGroup.com. Please include your name, phone number, and the product model number in the message.

Legal

Actual product may differ slightly from photograph. BloChair is a trademark of B&D GROUP, LLC. ©2018. All rights reserved. Distributed by B&D Group, Miami, FL.

MODIFICATION NOT APPROVED BY B&D GROUP, LLC. VOIDS WARRANTY.

www.BandDGroup.com • www.BloChair.com



MADE

WARNING:

Adult supervision required for inflation, deflation and maintenance. Follow all safety instructions to avoid serious injury.

- For household/residential use only.
- This chair is not intended for infants or persons with limited mobility.
- Place the chair in a safe area before use, making sure that there are no sharp edges, steps, drops, or breakable items nearby.
- Use on flat surfaces only. Do not use this chair on abrasive surfaces or near sharp or pointed objects.
- Keep this chair away from heaters, flames, sparks, or any heat source.
- Do not use this chair while using hot or sharp objects.
- Store your BloChair in a clean dry place at room temperature (above $50^{\circ}F/10^{\circ}C$). Storing your Chair under $50^{\circ}F$ ($10^{\circ}C$) and over $100^{\circ}F$ ($38^{\circ}C$) may affect its performance and will not be covered under warranty.
- Do not jump on the chair.

CAUTION:

Do not place on rough ground or near sharp objects as this may cause damage to your chair.

LIMITED 90-DAY WARRANTY

B&D Group, LLC, warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 90 days from the date of purchase. If any such defect is discovered within the warranty period, B&D Group, LLC. will repair or replace the unit free of charge upon receipt of the unit, shipping postage prepaid and insured to the factory address received from Customer Service. The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of any panels voids all warranties. This warranty does not cover cost of repairs made or attempted outside the factory. Any appicable implied warranties, including warranties of merchantability and fitness are hereby limited to 90 days from the date of purchase. Expressed or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply. The only authorized service center in the United States would be communicated from Customer Service. Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter detailing the complaint or issue, along with your daytime telephone number, name and address inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to Service@BandDGroup.com, specifying the model number and the problem.

PLEASE DO NOT SEND YOUR UNIT WITHOUT RECEIVING AN ESTIMATE FOR SERVICING. WE CANNOT STORE YOUR UNIT.







INSTRUCTION & CARE MANUAL IMBC200

GETTING TO KNOW YOUR BLOCHAIR®

Congratulations on your purchase of the BloChair. The BloChair family of products are comfortable, durable, and fully adjustable. Manufactured with heavy-duty PVC and 100% waterproof, the BloChair is ideal for use both indoors and outdoors.

For more information about your BloChair and other great BloChair products, visit www.BloChair.com!



GETTING TO KNOW YOUR BLOCHAIR®

Preparation of your inflatable chair requires no tools. However, for easiest setup, we recommend using an electric pump.

Locate the valves on the bottom of the chair. You will find two valves on the BloChair inflatable chair, and one on the inflatable ottoman. Each valve fills one chamber of the chair.

For personalized comfort, adjust your chair to your preferred firmness by adding or releasing air to each chamber. Full inflation will make the chair very firm, and a slightly lower inflation will create a beanbag effect, allowing you to sink into the chair. Please use caution not to overinflate the chair.

INFLATING & DEFLATING YOUR BLOCHAIR®

To Inflate:

- 1. Open your BloChair and lay it out on a flat surface.
- 2. Locate each air valve on your BloChair.
- Inflate each chamber of your BloChair to your preferred pressure, making sure not to overinflate.
 - Small Valve

To fill the small valve, insert the slim nozzle of an electric air pump into the valve opening and turn the pump on. You can also inflate this area by mouth, by pinching the valve gently to open the airway, and then blowing air into the chamber.

Large Valve

To fill the large valve, open the valve completely exposing the largest valve opening. Insert the large nozzle of an electric air pump into the valve and turn the pump on. You can also inflate this area by mouth. On some models, you may need to pinch the valve gently to open the airway, and then blow air into the chamber to fill it.

4. Close each valve and press the closed valve into the inflatable so that it is flat with the surface.

To Deflate:

- 1. Open the air valve to release the air. Pinch the valve open for best results.
- 2. For fastest results, use an electric air pump with the hose in the 'Deflate' position.

NOTE: For the Glitter Inflatable BloChair -


When deflating with an electric pump, be careful to avoid vacuuming the glitter.

CAUTION:

Inflation should only be performed by an adult.

TO INFLATE with BLOW DRYER ADAPTER (Some Models)

- Open your BloChair and lay it out on a flat surface. Locate each air valve on your Inflatable Chair.
- 2. Inflate the small chamber by blowing into the small air valve with your mouth.
- 3. Inflate the large chamber with your Blow Dryer Adapter:
 - Screw the nozzle onto the Blow Dryer Adapter.
 - Slide the wide end of the adapter over the 2" circular air vent on your hair dryer. Depending on your model hair dryer, the fit may be slightly loose or tight.
 - Open the valve completely exposing the largest valve opening.
 - Insert the nozzle of the Blow Dryer Adapter into the large valve opening.
 - Turn your hair dryer on the 'COOL' setting. Some dryers also have a 'Cool' button. Press this during use. Continue holding the 'Cool' button (if available) until the chamber is full.



NOTE: The Blow Dryer attachment can be used with most standard hair dryers to fill your Inflatable Chair to about 90% capacity. To increase the air pressure in your chair, you may need to add additional air by blowing with your mouth, or by using an electric pump.

CAUTION: If your chair, hair dryer, or Blow Dryer Adapter become hot during use, turn the dryer off and allow to cool before continuing. Use only on 'Cool' setting. Follow all instructions from your hair dryer manufacturer.